



CANON DR-5010 FEED TRAY REPLACEMENT GUIDE

1. Turn off the scanner power or unplug the power cord.
2. Remove the broken feed tray.
3. Install the replacement feed tray by inserting one of the hinge pins in the socket on the scanner.



4. Now carefully pull the pin on the opposite end until it can slide into that socket. If you apply too much pressure the pin hinge will break so be careful. Turn the scanner back on or plug in the power.

